

---

# WARMING DRAWER SAFETY & WARNINGS

---

Safety and warnings	3
Service and warranty	8
SIKKERHEDSFORANSTALTNINGER OG ADVARSLER   DA	9
VEILIGHEID EN WAARSCHUWINGEN   DUT	19
TURVALLISUUS JA VAROITUKSET   FIN	29
SÉCURITÉ ET AVERTISSEMENTS   FR	39
SICHERHEITS- UND WARNHINWEISE   DEU	49
PRECAUZIONI DI SICUREZZA E AVVERTENZE   ITA	59
SIKKERHET OG ADVARSLER   NOR	69
SÄKERHET OCH VARNINGAR   SWE	79
בטיחות ואזהרות   HEB	89

**FISHER & PAYKEL**

NZ AU UK IE EU SG

## **WARMING DRAWER**

---

WB60SDEI3, WB60SDTEI3, WB60SMG3, WB60SMTG3, WB60SMB3,  
WB60SMTB3, WB60SCX3, WB60SCTX3, WB76SDEI3, WB76SMG3,  
WB76SMB3, WB76SCX3, WB76SPEX3

**⚠ WARNING!**



**Electric Shock Hazard**

Failure to follow this advice may result in electric shock or death.

- If the product is damaged, switch the appliance off and disconnect it from the power supply to avoid possible electric shock.

**⚠ WARNING!**



**Cut Hazard**

Failure to use caution could result in injury.

- Take care: some edges may be sharp.
- Do not put fingers in the drawer when closing.

**⚠ WARNING!**



**Hot Surface Hazard**

Failure to follow this advice could result in burns and scalds.

- To avoid burns and scalds, keep children away from this appliance.
- Surfaces of the appliance may become hot enough to cause burns.
- Do not touch heating elements or interior surfaces of the appliance. Heating elements may be hot, even when they are dark in colour.
- Use protective gloves when handling hot surfaces.
- During and after use, do not touch or let clothing or other flammable materials contact heating elements or interior surfaces of the appliance until they have cooled.

**⚠ WARNING!**



**Fire Hazard**

Failure to follow this advice may result in overheating, burning, and injury.

- Flammable materials should not be stored in the appliance or near its surface.

**⚠ WARNING!**



**Tipping Hazard**

This product may tip. Keep children away and take care. Failure to follow this advice may result in injury.

- The drawer must be secured in place by supplied screws.
- Ensure there is a fixed shelf directly above the drawer if it is not installed under another product.

**READ ALL INSTRUCTIONS**

**WARNING!**

To reduce the risk of fire, electrical shock, injury to persons or damage when using the

# SAFETY AND WARNINGS

**appliance, follow the important safety instructions listed below. Read all the instructions before using the appliance. Use the appliance only for its intended purpose as described in these instructions**

## **General Use**

- This appliance is designed for use in a normal domestic (residential) environment.
- Do not use the appliance outdoors.
- Children should be supervised to ensure that they do not play with the appliance.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- To avoid hazard due to instability of the appliance, it must be fixed in accordance with installation instructions.
- Keep the operating panel clean and dry. Wash and dry your hands before operating the drawer to ensure the buttons will respond properly.
- Avoid drying food types with high moisture content e.g. tomatoes or pineapple.
- Do not store flammable substances, liquid or alcohol in the drawer as they can be easily ignited.

## **Installation**

- Ensure your appliance is properly installed according to the installation guide and earthed by a qualified technician.
- Ensure this appliance is connected to a circuit which incorporates an isolating switch providing full disconnection from the power supply.
- Do not install or operate the appliance if it is damaged or not working properly. If you receive a damaged product, contact your local dealer or installer immediately.
- Do not install the appliance near a hot gas or electric burner or in a heated oven.

## **Servicing**

- Check the appliance for any damage inside or outside surface of the appliance. Do not use damaged cord or plug. If there is any damage, do not operate the appliance. Contact a Fisher & Paykel trained and supported service technician.
- Do not repair or replace any part of the appliance unless specifically recommended in this user guide. All other servicing must be done by a qualified person or Fisher and Paykel trained and supported service technician.

## **Cleaning and maintenance**

- Ensure the appliance is turned off before cleaning the drawer.

## SAFETY AND WARNINGS

- Unplug from the power outlet and allow the appliance to cool down after use before cleaning the drawer.
- Cleaning and user maintenance shall not be undertaken by children without supervision.
- Use a moderately damp cloth for cleaning. Do not spray water outside or inside the appliance. Water can cause damage inside the appliance.
- Do not use aggressive or abrasive detergent or sharp metal scrapers for cleaning the the appliance. This can scratch the surface which can cause the glass to shatter.
- Do not use a steam cleaner.

### Safety

- Do not touch hot surfaces.
- The appliance and its accessible parts may become hot during use. Children less than 8 years old shall be kept away unless continuously supervised.
- Do not sit or lean on the appliance. Damage to the surface of the glass may cause it to shatter.
- Do not store hazardous objects that can explode, like containers with gas or air chambers (eg spray cans).
- Do not immerse cord, plug or other parts in water or other liquid to protect against electrical shock. Do not let the cord hang over the edge of table or counter, or in a heated oven.
- Do not use accessory attachments that are not recommended.

### Packaging disposal

- Remove packaging and recycle materials that can be reused.
- Dispose packaging materials in accordance with local regulations on waste disposal.


## SAVE THESE INSTRUCTIONS

# SAFETY AND WARNINGS

## European directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE)

### The Waste Electrical and Electronic Equipment Regulations 2013

This appliance is marked according to the above regulations. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.

The symbol  on the product, or on the documents accompanying the product, indicates that this appliance may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. Disposal must be carried out in accordance with local environmental regulations for waste disposal. For more detailed information about treatment, recovery and recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

### Power Consumption per (EU) 2023/826

STANDBY POWER* (WATTS)	TIME TO STANDBY** (MINUTES)	OFF MODE POWER (WATTS)
0.4	5	0.39

\*Standby power for electric cooking appliances is calculated using the following Standard:  
EN 50564 – Electrical and electronic household and office equipment – Measurement of low power consumption.

\*\*Time to Standby for electric cooking appliances is calculated using the following Standard:  
EN 50643 – Electrical and electronic household and office equipment – Measurement of networked standby power consumption of edge equipment.



### **To access your Warranty and Service Guide**

Scan the QR code with your smartphone to access your warranty and book a service, or refer to your separate warranty and service book or view online at:

#### **New Zealand**

<https://www.fisherpaykel.com/nz/help-and-support/warranty-information>

#### **Australia**

<https://www.fisherpaykel.com/au/help-and-support/warranty-information>

#### **United Kingdom**

<https://www.fisherpaykel.com/uk/help-and-support/warranty-information>

#### **Ireland**

<https://www.fisherpaykel.com/ie/help-and-support/warranty-information>

#### **Europe**

<https://www.fisherpaykel.com/eu/help-and-support/warranty-information>

#### **Singapore**

<https://www.fisherpaykel.com/sg/help-and-support/warranty-information>

This product has been designed for use in a domestic (residential) environment. This product is not designed for any commercial use. Any commercial use by the customer will affect this products Manufacturer's Warranty.

For spare parts, please contact Fisher & Paykel Customer Care. Spare parts are available for all Fisher & Paykel products for a minimum period of 10 years from the date of manufacture.

