
COMPACT COMBI-MICROWAVE OVEN FIRST USE

Get to know your appliance	3
Set up the oven	6
Select a cooking method or function	7
Set the timer	9
Set Delayed cook or Auto Off	10
Use the temperature sensor	11
Use Microwave assist	12
Use Multi shelf	13
Connect to Wi-Fi	14
Enable Remote mode	15
Turn Sabbath mode on	16
Enable Voice to open	17
Cooking methods and functions	18
Clean and maintain your oven	19

FISHER & PAYKEL

NZ AU SG

COMPACT COMBI-MICROWAVE OVEN

MINIMAL

OM76NMUB3, OM76NMUG3, OM76NMUNB3, OM76NMUNG3,
OM60NMUNB5, OM60NMUNG5, OM60NMUB5, OM60NMUG5,
OM60NMTB5, OM60NMTG5

CONTEMPORARY

OM76NCUDX3, OM60NCUDX5, OM60NCTDX5

PROFESSIONAL


OM76NPUX3

GET TO KNOW YOUR APPLIANCE




How to get the best results from your oven

- Download the app to use remote mode and get updates.
- Set up and condition the oven before you use it.
- Clean the oven regularly.
- Register your product to get streamlined service support.



GET TO KNOW YOUR APPLIANCE




HOME SCREEN

Control dial*	• Turn the dial to scroll. • Press to select. • Press and hold to go back.
Open Door button**	Press and hold to open or close the oven door.
Power button	Press and hold to turn the display on when oven is in standby. The oven will go into standby after a period of inactivity, and the display and clock will turn off. If Remote Mode is enabled, the power button will pulse when oven is in standby.
Menu	Press to access additional features and settings.
Quickstart	Press to quickly set and start a microwave function.
Cooking methods	Choose from a range of optimised cooking methods or traditional functions.

*Some models only

**Handleless models only



MENU		
	LIGHT	Press LIGHT to turn the oven lights ON/OFF .
	TIMER	Set a timer to keep track of cooking times or as a general timer. The timer does not turn the oven off.
	DRY	Run a dry cycle to help remove any moisture from the oven. Refer to Care and Maintenance guide for full instructions.
	LOCK	Lock the controls to prevent accidental use. When locked, the controls will be unresponsive and the appliance will not turn on. Press and hold the screen anywhere to unlock.
	SETTINGS	Adjust the settings to suit your preferences or set up a Wi-Fi connection.
	REMOTE	Connect appliance to your mobile device to operate it remotely via the app.
	BACK	Go back one level.
	EXIT	Press to return to the home screen.


SET UP THE OVEN

We recommend conditioning your oven for 1 hour before initial use to eliminate any manufacturing residue. A small amount of smoke may be present. Ensure the kitchen is well ventilated.




Remove cable ties

Cut and remove the cable ties that are securing the shelves and trays.



Condition the oven

1. Select **BAKE**, then **SKIP**, and set the oven to 200°C for 30 minutes.



2. Select **OPTIONS, CHANGE FUNCTION**, and set oven to **FAN GRILL** for 5 minutes, then **FAN FORCED** for 20 minutes.


Allow to cool completely, then wipe clean with a damp cloth and mild detergent.

SELECT A COOKING METHOD OR FUNCTION


Select a cooking method for an optimised cooking environment, or choose from a range of traditional cooking functions, including microwave-only, convection and microwave, or a convection-only function.



1. Position the shelves at the desired height.
Tilt and pull to remove.
To refit, slide rack between rails on the side racks. Ensure the guard rail is at the back.




2. Select a cooking method or function.



3. Select a food category or function as required.


SELECT A COOKING METHOD OR FUNCTION



4. Adjust the temperature, microwave power level or cook time if needed.


Microwave-only methods

Place food in oven, then press **START**.



Microwave and convection methods

Place food in the oven when prompted, then press **CONFIRM**.



Convection methods


Place food in the oven when preheat ends to prevent burning. A preheat progress bar will show while the oven is heating.

Press **PAUSE** or **STOP** at any time during microwave or convection cooks to stop cooking.


SET THE TIMER




Use the timer to keep track of cooking times or as a general timer. The timer does not turn the oven off.



1. Select **TIMER** from the menu or from the cooking screen.



2. Scroll to set the desired duration, then press **CONFIRM** to start the countdown.




3. The remaining time will show on the screen. Press it to adjust or cancel the timer.

When the timer is complete, an alert will sound and a message will show on the screen. Press **DONE** to dismiss the message.

SET DELAYED COOK OR AUTO OFF




You can set DELAYED COOK or AUTO OFF when using most cooking methods or functions. Use DELAYED COOK to set the oven to turn on later, cook for a set duration and turn off at a set time. Use AUTO OFF to set the oven to turn off after a set duration.



Press **OPTIONS** on the cooking screen, then select **DELAYED COOK** or **AUTO OFF**.



Delayed cook
Set a cook duration and a cooking end time, and press **CONFIRM**.
Cover food or place it on a lower shelf in oven to prevent burning as the oven preheats.
Not recommended with **GRILL**, **FAN GRILL**, **PROOF**, **DEFROST** or **AIR FRY**.




Auto off
Set a cook duration, and press **CONFIRM**.
The oven will turn off after the set duration.

USE THE TEMPERATURE SENSOR




Use the wired temperature sensor to monitor your cook to achieve your desired doneness.

Insert the sensor into the thickest part of the protein, avoiding fat and bone, and ensure the tip doesn't protrude or touch cookware.




1. Select a cooking method or function and press **OPTIONS**, then select **TEMP SENSOR**.



2. Select the relevant protein and desired doneness or removal temperature, then press **START**.

Allow your oven to preheat if necessary.




3. Place food in the oven. Plug the sensor into the socket on the inside-left of the oven until it clicks into place, then start the cook.

Rest meat before serving to allow the internal temperature to rise.


USE MICROWAVE ASSIST




Use the MICROWAVE ASSIST option to speed up cooking. The power level will be set automatically to suit the cooking method and food type. Ensure all cookware is microwave safe before turning on.



1. Select a cooking method and press MICROWAVE ASSIST.



2. Select ON, then CONFIRM.




3. Ensure cookware is microwave safe, then press START. Press MICROWAVE ASSIST again to turn it off.


USE MULTI SHELF




Use the MULTI SHELF option so heat distributes evenly when you cook food on more than one shelf at a time. You can turn it on or off before and during cooking.



1. Select a cooking method or function and press MULTI SHELF.



2. Press ON, then CONFIRM.




3. Press START, and allow your oven to preheat if necessary before putting the food in. Press MULTI SHELF again to turn it off.

CONNECT TO WI-FI




Connect your appliance to your home wireless network to receive updates and connect to the app.

It may take up to 10 minutes to connect your appliance.




On your mobile device

Scan the QR code to download the app, then create an account and add your appliance.



On your appliance

1. Ensure your home Wi-Fi network is on, then go to MENU and select SETTINGS.




2. Select WI-FI and follow the onscreen instructions to connect.


ENABLE REMOTE MODE




Enable REMOTE MODE to operate your appliance remotely via the app.



1. Go to MENU, and select REMOTE.



2. Select ON, then press CONFIRM.



Disable Remote Mode

Go to MENU, and select REMOTE. Select OFF, then press CONFIRM.


TURN SABBATH MODE ON

For the Sabbath observant. Sets your oven to heat continuously for as long as needed. The display will be unresponsive and no tones or alerts will sound. Your oven will stay in Sabbath mode until cancelled. Use the supplied door-opening tool to open handleless models when Sabbath Mode is on.


LOW
Keep hot food warm

MODERATE
Reheat cold food


HIGH
Cook raw food



1. Go to **SETTINGS** and select **SABBATH MODE**.



2. Set a heat level and press **CONFIRM**. Follow the onscreen instructions to set the oven light on or off and to set a **SABBATH MODE** duration.




3. The oven will stay in **SABBATH MODE** until the set duration has passed or until cancelled. Press and hold the screen to cancel **SABBATH MODE**.


ENABLE VOICE TO OPEN

Enable 'Voice to open' on handleless models to open the oven door. Your appliance must be connected to Wi-Fi and have Remote Mode enabled. Voice control also requires a smart speaker or your mobile device to control the oven door.

Only use voice control when you can see the oven and it is safe to open the door.



1. Go to **SETTINGS** and select **VOICE OPEN DOOR**.



2. Select **ON**, then **CONFIRM**.
Follow the instructions on the screen and in the app to complete the setup.

Method-led cooking lets you select what you want to cook and how you want to cook it. Your oven will then recommend the optimal heat type and temperature for perfect cooking results. Explore the full range of methods and functions available.

Methods

Cooking methods support you to achieve your desired result across a range of food categories. Each method may be supported by one or more functions.

Air fry	Proof
Bake	Reheat
Defrost	Reverse sear
Dehydrate	Roast
Grill	Slow cook
Melt	Warm
Microwave	Regenerate

Functions

Functions are specific cooking environments. They deliver heat in a fixed way and can involve either a single step or a sequence of steps.

Air fry	Grill + microwave
Bake	Melt
Classic fan	Microwave
Fan bake	Reverse sear
Fan forced	Roast
Fan forced + microwave	Roast + microwave
Fan grill	Slow cook
Fan grill + microwave	Vent bake
Grill	Air fry

CLEAN AND MAINTAIN YOUR OVEN

Make these steps a regular part of your cleaning routine to get the best results from your appliance.

Clean door glass after each use

Wipe the door glass clean after each use to prevent stains becoming baked on.

Clean inside of the oven after each use

Clean up any easy-to-reach spills, food or grease stains in the oven to prevent them becoming baked on.



Scan the QR code or visit fisherpaykel.com and search for your model code to see Care, maintenance and troubleshooting information.

