BUILT-IN COFFEE MAKER
SAFETY & WARNINGS

Safety and warnings 3
Service and warranty 8

SIKKERHEDSFORANSTALTNINGER OG ADVARSLER | DA 11
VEILIGHEID EN WAARSCHUWINGEN | DUT 21
TURVALLISUUS JA VAROITUKSET | FIN 31
SÉCURITÉ ET AVERTISSEMENTS | FR 41
SICHERHEITS- UND WARNHINWEISE | DEU 51
בטיחות ואזהרות | HEB 62
PRECAUZIONI DI SICUREZZA E AVVERTENZE | ITA 75
SIKKERHET OG ADVARSLER | NOR 85
SÄKERHET OCH VARNINGAR | SWE 95
安全提示 | ZH 105

FISHER & PAYKEL

NZ AU UK IE EU SG CN

BUILT-IN COFFEE MAKER

EB60MSG3, EB60MSB3, EB60CSX3, EB76PSX3

IMPORTANT SAFETY INSTRUCTIONS

Your safety is important to us. Keep the following instructions in mind when you are using your coffee maker.

Failure to observe the instructions could result in electric shock, serious injury, burns, fire, or damage to the appliance.

Save these instructions.

⚠ WARNING!



Cut Hazard

- Take care – some edges are sharp.
- Failure to use caution could result in injury or cuts.

⚠ WARNING!



Electrical shock hazard

- Never touch the appliance with damp hands.
- Never touch the plug with damp hands.
- Make sure the socket used is freely accessible at all times, enabling the appliance to be unplugged when necessary.
- Unplug directly from the plug only.
- Never pull the power cable as you could damage it.
- To disconnect the appliance completely, place the main switch on the side of the appliance in the 0 position.
- If the appliance is faulty, do not attempt to repair. Turn it off using the main switch, unplug from the mains socket and contact Customer Care.

⚠ WARNING!



Hot surface hazard

Accessible parts may become hot when in use.

- This appliance produces hot water and steam may form while it is in operation.
- Avoid contact with splashes of water or hot steam. Use knobs and handles.

READ THESE INSTRUCTIONS

General use

- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Designated use: this appliance is designed and made to prepare coffee and milk based beverages and hot water. Any other use is considered improper and thus dangerous. The manufacturer is not liable for damage deriving from improper use of the appliance.
- This appliance is not suitable for commercial use.
- This is an household appliance only. It is not intended to be used in: staff kitchen areas in shops, offices and other working environments; farm houses; by clients in hotels, motels and other residential type environments; bed and breakfast type environments.
- The surface of the heating element remains hot after use and the outside of the appliance may retain the heat for several minutes depending on use.
- Appliances with removable cord: avoid splashes of water on the power cord connector or socket at the back of the appliance.
- CAUTION: Do not use the appliance if the enclosure, glass surfaces (if any) and containers are damaged or have visible cracks.
- This appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazard involved. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised. Keep the appliance and its cord out of the reach of children aged less than 8 years.
- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- When not in use and before cleaning, always unplug the appliance.
- CHOKING HAZARD. The appliance might contain small parts. Some of those small parts might be required to get disassembled during cleaning and maintenance operations. Handle with care and keep small parts out of reach of children.
- Do not hold on to the coffee machine when it is out of the cabinet.

- Do not rest recipients containing liquids or inflammable or corrosive materials on top of the appliance. Place the accessories required to make the coffee (the measure for example) in the special holder. Do not rest large objects which could obstruct movement or unstable objects on the appliance.
- Do not allow children and animals to stop or linger near the appliance when it is pulled out of the cabinet.
- Do not leave the machine pulled out of the cabinet when it is being used.
- Do not leave the machine pulled out of the cabinet when it is not needed.
- Do not use the appliance when pulled out from the cabinet. Make sure the appliance is inactive before pulling it out. The only exception is adjusting the coffee mill which must be done with the machine pulled out (see use and care instructions).

Installation

- Installation must be performed by a qualified professional in compliance with legislation in force in the country of installation (see installation instructions).
- CAUTION: Install or place the appliance on a worktop higher than 850mm from the floor.
- This appliance can be installed over a built-in oven if the latter is fitted with a cooling fan at the rear (maximum microwave power: 3 kW).
- Never install the appliance in rooms where the temperature may drop to 0°C or lower.
- Customise the water hardness as soon as possible following the instructions in the use and care instructions.
- Install the machine according to the instructions in the handbook to guarantee there are no spills when it is pulled out from the cabinet.

Connection

- Check that the mains power supply voltage corresponds to the value indicated on the rating plate on the bottom of the appliance.
- Connect the appliance to an efficiently earthed and correctly installed socket with a minimum current rating of 10A only. If the power socket does not match the plug on the appliance, have the socket replaced with a suitable type by a qualified professional.
- To comply with safety directives, an omnipolar switch with a minimum contact distance of 3 mm must be installed.
- Do not use multiple sockets or extensions.
- Safety cutout devices must be included in the mains power supply in compliance with the installation regulations in the country concerned.

Servicing

- If the plug or power cable is damaged, it must be replaced by a qualified person or Fisher and Paykel trained and supported service technician only to avoid all risk.
- Use original or manufacturer recommended accessories and spare parts only.

Cleaning and maintenance

- Clean all the components thoroughly, taking particular care with parts in contact with the coffee and milk.
- Cleaning and user maintenance shall not be made by children without supervision.
- Never immerse the appliance in water.
- CAUTION: To prevent damage to the appliance do not use alkaline cleaning agents when cleaning, use a soft cloth and a mild detergent.
- Never turn off the machine during descaling.

- The first time you use the appliance, or if it is not used for more than 3 or 4 days, rinse all removable accessories which may come into contact with water or milk with hot water.
- If the appliance is not used for more than 3 or 4 days, before making the first beverage, rinse the water circuit as described in the use and care instructions.
- You should carry out automatic cleaning and guided maintenance scrupulously when proposed by the appliance through the display or the lights described in the use and care instructions.
- Fill with fresh drinking water.
- Empty the water tank if the appliance is not used for extended periods (holidays etc.).
- Replace the water if the appliance is not used for more than two days.
- When using the machine for the first time, prepare these items without drinking them: 4 hot coffee brews; 1 hot water cycle.

Packaging disposal

- Keep all packaging (plastic bags, polystyrene foam) away from children.
- The packing elements (plastic bags, polystyrene foam, etc.) should be kept out of reach of children.

Hazardous Substances Declaration Table and Marking

1. Information on the Hazardous Substances declaration for this product is available online. Go to www.fisherpaykel.com/cn/zh_CN/specify and search by appliance type, product name or model.

2. The RoHS mark and the Environment-Friendly Use Period (EFUP) can be identified on the rating label affixed to the product.

Product Quality Certificate (CN)

Fisher & Paykel Appliances Ltd hereby declares that:

All models listed in the User Guide are designed in accordance with the applicable Chinese national product safety standards or corresponding international standards and manufactured under an established factory quality management system. The model number and manufacture date can be identified on the product rating label. Accordingly, the listed models comply with the requirements of the People's Republic of China Product Quality Law.



This appliance conforms to EC Regulation 1935/2004 on materials and articles intended to come into contact with food.

European directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE)

The Waste Electrical and Electronic Equipment Regulations 2013

This appliance is marked according to the above regulations. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.

The symbol  on the product, or on the documents accompanying the product, indicates that this appliance may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. Disposal must be carried out in accordance with local environmental regulations for waste disposal. For more detailed information about treatment, recovery and recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Power Consumption per (EU) 2023/826

STANDBY POWER* (WATTS)	TIME TO STANDBY** (MINUTES)	OFF MODE POWER (WATTS)
0.2	29	N/A

*Standby power for electric cooking appliances is calculated using the following Standard: EN 50564 – Electrical and electronic household and office equipment – Measurement of low power consumption.

**Time to Standby for electric cooking appliances is calculated using the following Standard: EN 50643 – Electrical and electronic household and office equipment – Measurement of networked standby power consumption of edge equipment.

To access your Warranty and Service Guide

Scan the QR code with your smartphone to access your warranty and book a service, or refer to your separate warranty and service book or view online at:

New Zealand
https://www.fisherpaykel.com/nz/help-and-support/warranty-information

Australia
https://www.fisherpaykel.com/au/help-and-support/warranty-information

United Kingdom
https://www.fisherpaykel.com/uk/help-and-support/warranty-information

Ireland
https://www.fisherpaykel.com/ie/help-and-support/warranty-information

Europe
https://www.fisherpaykel.com/eu/help-and-support/warranty-information

Singapore
https://www.fisherpaykel.com/sg/help-and-support/warranty-information

China
https://www.fisherpaykel.com/cn/help-and-support/warranty-information

This product has been designed for use in a domestic (residential) environment. This product is not designed for any commercial use. Any commercial use by the customer will affect this products Manufacturer's Warranty.

For spare parts, please contact Fisher & Paykel Customer Care. Spare parts are available for all Fisher & Paykel products for a minimum period of 10 years from the date of manufacture.

Before you call for service or assistance

Check the things you can do yourself. Refer to the installation instructions and your user guide and check that:

1 Your product is correctly installed.

2 You are familiar with its normal operation.

If after checking these points you still need assistance or parts, please refer to the Service & Warranty book for warranty details and your nearest Authorised Service Centre, Customer Care, or contact us through our website www.fisherpaykel.com.

Complete and keep for safe reference:

Model _____

Serial No. _____

Purchase Date _____

Purchaser _____

Dealer _____

Suburb _____

Town _____

Country _____

FISHERPAYKEL.COM

© Fisher & Paykel Appliances 2026. All rights reserved.

The models shown in this guide may not be available in all markets and are subject to change at any time.

The product specifications in this guide apply to the specific products and models described at the date of issue. Under our policy of continuous product improvement, these specifications may change at any time.

For current details about model and specification availability in your country, please go to our website or contact your local Fisher & Paykel dealer.

433145A 07.26