DISHDRAWER™ DISHWASHER
FIRST USE

Get to know your appliance	3
Load dishware	5
Load detergent	6
Use rinse aid	7
Select a suitable cycle	8
Select a suitable modifier	9
Standards testing	9
Hygiene cycle	9
Set a cycle	10
Set up Wi-Fi and remote mode	12
Adjust the settings	13
Settings	14
Delay Start and controls	16
Maintain wash performance	17

FISHER & PAYKEL


US CA

CONTEMPORARY DISHDRAWER™ DISHWASHER


DD24D2CX2, DD24DT2CX2, DD24S2CX2, DD24ST2CX2

How to get the best results from your dishwasher

- Check that your dishware is dishwasher safe
- Keep the spray arm clear of obstructions
- Load items so water from the spray arm can reach them
- Use correct detergent quantity
- Use liquid rinse aid
- Clean the filter
- Run regular deep clean cycles
- Descale to remove mineral buildup
- Register your product to get streamlined service support.




*some models only



Wash program selector	Press to cycle through and select a wash program.
Wash modifier selector	Press to select a wash modifier.
START button	Press to start or cancel a wash cycle.
Wash program indicators	Indicate which program is selected.
Wash modifier indicators	Indicate which modifier is selected.
DELAY START indicator	Indicates when **DELAY START** is set.
LOCK indicator	Indicates when drawer is locked.
Remote mode indicator	Indicates when product has remote mode enabled.

Tips for energy efficiency

- Load the dishwasher to capacity.
- Remove large food scraps, but do not pre-rinse dishes as this uses more water and energy.
- Select the most appropriate program for each load. See 'Select a suitable cycle' for recommendations.



Load items effectively

Space items evenly in the drawer, with cups and containers facing down, so water from the spray arm can reach them and drain away.



Check for obstructions

Check there are no items that will prevent the spray arm from rotating.



Load cutlery correctly

Load sharp knives with handles up. Mix spoons, knives and forks in each section to prevent nesting.

LOAD DETERGENT

We recommend:

- Premium powdered detergents and tablets to effectively clean dishes, utensils and filters in your dishwasher.

We do not recommend:

- Non-premium powdered detergents and tablets, as these can result in faster grease buildup and reduced wash performance.
- Detergent sheets, as these produce excessive foam.
- Handwashing dish detergents and laundry or other detergents.



If using powdered detergent

Press the latch to open the dispenser.

Add the recommended quantity of detergent, and close the dispenser. See Care and Maintenance guide for details.



If using tablets

Place a tablet directly into the cutlery basket, tablet tray, or the tub.


Ensure tablet is not touching cutlery or dishes.

USE RINSE AID

Rinse aid improves dry performance and prevents tarnishing on metal and streaks on glass and dishware. Fill the rinse aid dispenser before adding detergent.



1. Press the latch to open the dispenser. Push the rinse aid latch away from you to open compartment.



2. Pour rinse aid into the opening. If spilled, wipe immediately.



3. Close the rinse aid compartment and detergent dispenser.

SELECT A SUITABLE CYCLE

Each cycle is designed for a specific purpose and has different time, energy and water requirements. Choose a cycle that balances load type and efficiency to get the best results.


TIME | ENERGY | WATER

WASH PROGRAMS

ECO DEFAULT

For normally soiled dishes for optimum water and energy use.


Typical items: plates, bowls, cutlery from regular meals



HEAVY DRY+, INTENSIVE

Designed for heavily soiled pots, pans and dishes.


Typical items: pots, pans, casserole dishes with baked-on food



MEDIUM DRY+, GENTLE

For dishes that are quite heavily soiled or to remove food that has been left overnight.


Typical items: plates with dried food, serving dishes



LIGHT DRY+, GENTLE

For very lightly soiled dishes with easy-to-remove soils.


Typical items: plates, bowls, cups, plastic items and glassware with minimal residue



60MIN DRY+, INTENSIVE

For dishes that are quite heavily soiled or food that has been left to dry overnight. No drying.


Typical items: plates with dried food, serving dishes



HYGIENE DRY+

For dishes that need to be sanitised. This cycle increases rinse temperature to 158°F.

Typical items: baby bottles, storage jars



SELECT A SUITABLE MODIFIER

WASH MODIFIERS

DRY+

DRY+ increases the final rinse temperature and the length of the drying phase.

GENTLE

GENTLE lowers the water temperature and pressure.

INTENSIVE

INTENSIVE increases the water pressure and the length of the cycle.

DRAWER DRY

Drawer Dry is an essential function that protects your DishDrawer™ Dishwasher from moisture buildup. The low-power fan automatically starts after each wash cycle to dry the appliance. The fan may operate for up to several hours and will stop if the drawer is opened. In single drawer models, the fan will resume once the drawer is closed.


STANDARDS TESTING

Wash program standards tests are based on the **ECO** wash program. Standards testing information and wash data can be viewed online by going to https://www.fisherpaykel.com and searching your model code.

United States / Canada: Maximum 7 place settings per drawer.

HYGIENE CYCLE

The hygiene cycle raises the rinse temperature to 158°F and meets the sanitisation conditions required by Section 6, NSF/ANSI 184. A successful cycle will end as normal. If the HYGIENE cycle is interrupted, an alert will sound and the HYGIENE indicator will flash. Press start twice to clear alert. Repeat the cycle.



Setting a wash program

1. Press **WASH PROGRAM SELECTOR** > to scroll and select a wash program.


Press **START** ▷ then close the drawer.



Setting a wash modifier


Press **WASH MODIFIER SELECTOR** + to select a wash modifier.

Press **START** ▷ to start the wash, then close the drawer.




Pausing a wash

On the door of the drawer, press **START** ▶II, and wait for three short and one long tone before opening.




Resuming a wash

Press **START** ▷ to resume the wash, then close the drawer.



Cancelling a wash*

Press and hold **START** ▷ on the control panel to cancel. The drawer will turn off when water has drained.



Cancelling a wash*

Press and hold **START** ▶II on the door to cancel. The drawer will turn off when water has drained.

*some models only

SET UP WI-FI AND REMOTE MODE


Connect your appliance to your home Wi-Fi to get software updates, receive wash notifications, customise settings and control your wash cycles remotely.

Getting started

- Ensure your home Wi-Fi network is turned on and there is no wash cycle in progress.
- You will be given step-by-step guidance on your mobile device.
- It may take up to 10 minutes to connect your appliance.


On your mobile device:

1. Scan the QR code to download the app from www.fisherpaykel.com/connect.
2. Register and create an account.
3. Add your appliance and set up the Wi-Fi connection.



Connecting to Wi-Fi

Press and hold **WASH PROGRAM SELECTOR** > for five seconds. Follow instructions in the app to complete set-up.



Turning remote mode ON


Press and hold **WASH PROGRAM SELECTOR** > for two seconds.

ADJUST THE SETTINGS

Go to the app to adjust and customise your settings or follow the steps below to adjust settings directly on your dishwasher. Each setting is displayed using a different combination of indicator lights. Adjust a setting by matching the indicator combinations as shown in 'Settings'.


Before adjusting settings, clear active wash cycles and make sure the controls aren't in sleep mode:

- **If an indicator is flashing -** Press and hold **START** ▷ to cancel an active wash cycle.
- **If all indicators are off -** Press the **WASH PROGRAM SELECTOR** ❯ or close and open the drawer to wake up the controls.




Access settings


1. Press and hold **WASH PROGRAM SELECTOR** ❯ and **WASH MODIFIER SELECTOR** + together for four seconds.



2. Press **WASH MODIFIER SELECTOR** + to scroll through the settings.




3. Press **WASH PROGRAM SELECTOR** ❯ to change the setting within an option.




4. Press **START** ▷ to save and exit the menu, or press and hold to cancel at any time.

Settings apply to both drawers in double models.



Wi-Fi (recommended)


Connect your dishwasher to your home network to operate it via the app and to receive updates.



Auto power-on

Your DishDrawer™ Dishwasher is set to automatically power on for 30 seconds after a drawer is opened. This can be turned off.

HEAVY indicator light corresponds to ON/OFF.




Tones

Adjust tone settings. When set to **OFF,** all tones will be silenced except fault alerts.



Rinse aid

Control the amount of rinse aid dispensed from 0–5 units. Units correspond to wash program indicator lights. Defaults to 3.



Auto lock

Automatically lock the drawer after 30 seconds to prevent opening.




Default cycle

Automatically default to **ECO** when in standby mode. This can be turned off.




Setting DELAY START

Press and hold **START** ▷ to enter mode. Each tone indicates +1 hour (12 max). Release **START** ▷ at your chosen delay. Timer begins when you close the drawer. To cancel, press and hold **START** ▷ until **DELAY START INDICATOR** ◷ turns off.



Locking the controls

Press and hold **WASH MODIFIER SELECTOR** + until you hear a tone and **LOCK** 🔓 illuminates.



Unlocking the controls

Press and hold **WASH MODIFIER SELECTOR** + until **LOCK** 🔓 turns off.

MAINTAIN WASH PERFORMANCE

Make these steps a regular part of your cleaning routine to get the best results from your appliance.

Keep the spray arm clear

Check that nothing is obstructing the spray arm. Regularly remove and clean it with hot water and a cloth to unblock the spray holes.

Use correct detergent quantity

You may need to adjust detergent quantity based on local water hardness. Scan the QR code below for recommended detergent quantities.

Use rinse aid

Rinse aid prevents water beading on dishes, glasses and cutlery, so dishes dry faster and do not develop white spots.

Clean the filter

A blocked filter reduces the water pressure required to clean dishes. Remove and clean the filter regularly in hot, soapy water to remove food and grease buildup.

Run regular deep clean cycles

Run a cycle every few months to remove grease and buildup and more often if you use Eco detergents or low-temperature cycles. Use a premium dishwashing cleaner, follow label instructions, and run the **HEAVY** cycle.

Descale to remove mineral buildup

Fill the detergent dispenser and secondary compartment with citric acid crystals or descaler. Run the dishwasher on the **HEAVY** cycle followed by a wash program with detergent immediately after.

Care, maintenance and troubleshooting information

Scan the QR code or visit fisherpaykel.com and search for your model code.

DD24D2CX2, DD24DT2CX2, DD24S2CX2, DD24ST2CX2



FISHERPAYKEL.COM

© Fisher & Paykel Appliances 2026. All rights reserved.

The models shown in this guide may not be available in all markets and are subject to change at any time.

The product specifications in this guide apply to the specific products and models described at the date of issue. Under our policy of continuous product improvement, these specifications may change at any time.

For current details about model and specification availability in your country, please go to our website or contact your local Fisher & Paykel dealer.

434364A 10.26